









Art No. :96105 99318
www.eglo.com



1.








2.



EN

EN General Safety Information

Electrical installations may only be carried out by qualified electricians. Please note! Before proceeding with installation mains connecting cable must be de-energized (fuse turned off). Please note the following symbols and safety instructions, in order to avoid damage caused by incorrect assembly or use:

	Protection class 1: Lamps with this symbol connect them on the network side with the yellow/green protective earth to the protective earth terminal
	Protection class 2: for lamps with this symbol no protective conductor necessary for safe operation.
	Protection class 3: Only operate lamps with this symbol with Safety Extra Low Voltage (SELV). Only connect to SELV circuits.
	Minimum distance: This symbol explains the minimum distance of the illuminant to the illuminated, normally flammable surface.
	Downlights: This symbol explains that the lamp is not suitable for covering with thermal insulating material.

Changes: Do not make any changes to the lamp or its connecting cable.

Connecting cable: The exterior flexible cable of this light cannot be replaced. Scrap the lamp, if this cable is damaged.

Commissioning: Do not operate the lamp if it or its connecting cable shows visible signs of damage.






Non replaceable light sources: The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.

Care advice: Only clean lights when turned off, do not allow any moisture into connecting areas or on current-carrying parts. Cleaning agents can cause staining.

DE

Allgemeine Sicherheitshinweise

Elektroinstallation ist von Elektrofachkraft durchzuführen. Achtung! Vor Montagebeginn muss Netzanschlussleitung spannungsfrei sein (Si-cherung ausgeschaltet). Beachten Sie die nachstehend erläuterten Symbole und Sicherheitshinweise, um Schäden durch nicht fachgerechte Montage oder Gebrauch zu vermeiden:

	Schutzklasse 1: Leuchten mit diesem Symbol Netzseitig mit dem gelb/grünen Schutzleiter an die Schutzerdungsklemme anschließen
	Schutzklasse 2: für Leuchten mit diesem Symbol zum sicheren Betrieb keine Schutzleiter notwendig.
	Schutzklasse 3: Leuchten mit diesem Symbol nur mit Schutzkleinspannung betreiben. Anschluss nur an SELV Stromkreise.
	Mindestabstand: Dieses Symbol erläutert den Mindestabstand des Leuchtmittels zur angestrahlten, normal entflammaren Fläche.
	Downlights: Dieses Symbol erläutert, dass die Leuchte nicht geeignet ist um sie mit Wärmedämmmaterial abzudecken.

Veränderungen: Nehmen Sie keine Veränderung an der Leuchte oder deren Anschlussleitung vor.

Anschlussleitung: Die äußere flexible Leitung dieser Leuchte kann nicht getauscht werden. Verschrotten Sie die Leuchte, falls diese Leitung beschädigt ist.

Inbetriebnahme: Nehmen Sie die Leuchte nicht in Betrieb, wenn die Leuchte selbst oder deren Anschlussleitung sichtbare Schäden aufweisen.

Nicht auswechselbaren Lichtquellen : Die Lichtquelle dieser Leuchte ist nicht ersetzbar; wenn die Lichtquelle ihr Lebensdauerende erreicht hat, ist die gesamte Leuchte zu ersetzen

Pflegehinweis: Leuchte nur im ausgeschalteten Zustand reinigen, Keine Feuchtigkeit in Anschlussräumen oder an stromführende Teile bringen. Reinigungsmittel können Fleckenbildung verursachen.

Eglo Leuchten GmbH
Heiligkreuz 22, 6136 Pill, Austria