

Rim Аксессуар

W B BS



1 □ ■ ■■



2 □ ■ ■■

1 ■■ MOD058A-02BS
■ MOD058A-02B
□ MOD058A-02W

2 ■■ MOD058A-03BS
■ MOD058A-03B
□ MOD058A-03W

Совместимы с артикулами:
MOD058PL-L55B3K
MOD058PL-L55BS3K
MOD058PL-L55W3K
MOD058PL-L74B3K
MOD058PL-L74BS3K
MOD058PL-L74W3K
MOD058PL-L55W4K
MOD058PL-L55BS4K
MOD058PL-L55B4K
MOD058PL-L74BS4K
MOD058PL-L74W4K
MOD058PL-L74B4K

Совместимы с артикулами:
MOD058PL-L100B3K
MOD058PL-L100BS3K
MOD058PL-L100W3K
MOD058PL-L100W4K
MOD058PL-L100BS4K
MOD058PL-L100B4K